

**USDA**  
**NATURAL RESOURCES**  
**CONSERVATION SERVICE**  
  
**DELAWARE CONSERVATION**  
**PRACTICE STANDARD**  
  
**WASTEWATER TREATMENT**  
**STRIP**

**CODE 635**  
 (Reported by Ac.)

### **DEFINITION**

A treatment component of an agricultural waste management system consisting of a strip or area of herbaceous vegetation.

### **PURPOSES**

The purpose of this practice is to improve water quality by reducing loading of nutrients, organics, pathogens, and other contaminants associated with animal manure and other wastes, and wastewater by treating agricultural wastewater and runoff from livestock holding areas with:

- Rapid infiltration;
- Overland flow; or
- The slow rate process.

### **CONDITIONS WHERE PRACTICE** **APPLIES**

This practice applies:

- Where a treatment strip is a component of a planned agricultural waste management system.

- Where a treatment strip can be constructed, operated and maintained without polluting air or water resources.
- To the treatment of contaminated runoff from such areas as feedlots, barnyards, and other livestock holding areas.
- To the treatment of diluted wastewater such as milk house effluent and diluted silage leachate.

### **CONSIDERATIONS**

More than one overland flow treatment strip should be considered to allow for resting, harvesting vegetation, maintenance, and to minimize the potential for overloading.

Consider pretreating overland flow influent with solid/liquid separation to reduce organic loading, odor generation, and maintenance requirements.

Consider suspension of application to treatment strips when weather conditions are not favorable for aerobic activity or when soil temperatures are lower than 39° F. When soil temperatures are between 39° F and 50° F reduction of application rate and increased application period while maintaining the hydraulic loading rate constant should also be considered.

This practice has the potential to affect National Register listed cultural resources or eligible (significant) cultural resources. These may include archeological, historic, or traditional cultural properties. Care should be taken to avoid adverse impacts to these resources. Follow NRCS state policy for considering cultural resources during planning.

### **CRITERIA**

#### **Criteria Applicable to All Purposes**

The installation and operation of the wastewater treatment strip shall comply with all federal, state, and local laws, rules, and regulations, including DNREC , Guidance and Regulations Governing the Land Treatment of Wastes.

Conservation practice standards are reviewed periodically, and updated if needed. To obtain the current version of this standard, contact the Natural Resources Conservation Service.

Inflow to wastewater treatment strips shall be pretreated as appropriate.

Discharge to and through treatment strips shall be as sheet flow. Some means, such as a ditch, curb, or gated pipe, shall be provided to disperse concentrated flow and ensure sheet flow across the width (dimension perpendicular to flow length) of the treatment strip. Land grading and structural components necessary to maintain sheet flow throughout the length (dimension parallel to the flow) of the treatment strip shall be provided as necessary.

Permanent herbaceous vegetation consisting of a single species or a mixture of grasses, legumes, and/or other forbs adapted to the soil and climate shall be established in the treatment strip. Vegetation shall be able to withstand anticipated wetting and/or submerged conditions.

Clean water shall be diverted from the treatment strip to the fullest extent possible unless needed to promote vegetation growth in the treatment strip.

Treatment strips should be located outside of floodplains. However, if site restrictions require location within a floodplain, they shall be protected from inundation or damage from a 25-year flood event, or larger if required by law.

Designs shall be based on the latest edition of the Environmental Protection Agency Technology Transfer Process Design Manual for Land Treatment of Municipal Wastewater or other technically acceptable reference.

#### **Additional Criteria For Rapid Infiltration Treatment**

Rapid infiltration treatment refers to a specific remediation technique that utilizes the filtering capabilities of moderately and highly permeable soils. Treatment for this purpose shall consist of directing wastewater or contaminated runoff from a livestock holding area into a uniformly graded strip or area of herbaceous vegetation and allowing it to flow over and infiltrate the treatment strip. This method is not appropriate for treatment of wastewater containing high concentrations of nutrients.

Contaminated runoff shall be pretreated by solid/liquid separation utilizing a facility such as a

settling basin prior to discharge of liquid to the treatment strip.

The treatment strip shall be a uniformly graded strip or wide bottomed trapezoidal channel.

The treatment strip design shall be based on the runoff volume from the 25-year, 24-hour storm event from the livestock holding facility. It may be designed to infiltrate a portion or the entire volume of the design storm. This determination will be based on management objectives. The portion of the design volume not infiltrated shall be transferred to a storage facility unless discharge is permitted by applicable regulations.

The treatment strip's area requirements shall be based on the soil's capacity to infiltrate and retain runoff within the root zone and the vegetation's capability to utilize the nutrient loading. The soil's ability to infiltrate and retain runoff shall be based on its water holding capacity in the root zone, infiltration rate, permeability, and hydraulic conductivity. This determination shall be based on the most restrictive soil layer within the root zone regardless of its thickness. The anticipated nutrient loading shall not exceed the vegetation's agronomic nutrient requirement.

The infiltration strip design shall be such that the upper soil profile remains unsaturated except during storm events and returns to an unsaturated condition within two days following storm events. The water table shall be either naturally deep enough or artificially lowered so that the infiltrated runoff does not mingle with the native ground water. Infiltration strips shall not be planned where soil features such as cracking will result in preferential flow paths that transport untreated runoff from the surface to below the root zone.

#### **Additional Criteria for Overland Flow Treatment**

Overland flow treatment refers to a specific microbial remediation technique that has minimal infiltration of wastewater. Treatment by overland flow shall consist of the application of wastewater along the upper portion of a uniformly sloped strip of herbaceous-vegetation, allowing it to flow over the vegetated surface for aerobic treatment to a collection ditch.

The design hydraulic loading rate and application rate shall be selected based on consideration of the anticipated levels of pretreatment, quality of effluent, temperature, and other climatic conditions. A maximum hydraulic loading rate of 2.0 inches per day and an application rate of eight gallons per hour per foot of slope width shall be used unless higher rates can be justified by on-site studies.

The application period shall not exceed 12 hours per day and the application frequency not exceed 5 days per week unless longer application periods and frequencies can be justified based on local conditions.

The nutrients anticipated to infiltrate the treatment strip shall not exceed the vegetation's agronomic nutrient requirement.

Overland flow treatment shall be constructed on soils with low permeability. The design shall be based on the most restrictive soil layer within the root zone. The maximum allowable permeability shall be 0.2 inches per hour unless a natural or constructed barrier within the soil profile mitigates the potential of ground water contamination.

The minimum slope length for the applied wastewater shall be 100 feet.

The sloped areas to receive wastewater shall be uniformly graded to eliminate wastewater ponding and short-circuiting for the length of the flow. Slopes shall be equal to or greater than 2.0% but shall not exceed 8.0%.

Wastewater discharged from the treatment strip shall be transferred to a waste storage facility, a waste treatment lagoon, or other facility for further treatment and/or utilization unless discharge is permitted by regulations.

#### **Additional Criteria for Treating Wastewater With the Slow Rate Process**

The slow rate process refers to a specific remediation technique involving the application of wastewater to a vegetated surface for treatment as it flows down through the plant-soil matrix.

The design hydraulic loading shall be based on the most restrictive of two limiting conditions -

the capacity of the soil profile to transmit water (soil permeability) or in the nitrogen concentration in the water percolating below the root zone. The percolate nitrate-nitrogen concentration leaving the root zone shall not exceed 10 mg/L. The anticipated nutrient loading shall not exceed the vegetation's agronomic nutrient requirement.

Storage shall be provided when the amount of available wastewater exceeds the design hydraulic loading rate or for strip non-operating periods.

Wastewater shall be applied to the treatment strip utilizing a method that will result in an even application of the entire strip and a rate that does not exceed the infiltration rate of the soil.

### **PLANS AND SPECIFICATIONS**

Plans and specifications for establishment of this practice shall be prepared in accordance with the previously listed criteria. Plans and specifications shall contain sufficient detail to ensure success of the practice. Documentation shall be in accordance with the section "Supporting Data and Documentation" in this standard.

### **OPERATION AND MAINTENANCE**

An Operation and Maintenance (O&M) plan shall be developed that is consistent with the purposes of the practice, its intended life, safety requirements, and the criteria for its design. The plan shall include the following as appropriate:

1. Harvest treatment strip vegetation as appropriate to encourage dense growth, maintain an upright growth habit, and remove nutrients and other contaminants that are contained in the plant tissue.
2. Control undesired weed species, especially state-listed noxious weeds.
3. Inspect and repair treatment strips after storm events to fill in gullies, remove flow disrupting sediment accumulation, re-seed disturbed areas, and take other measures to prevent concentration flow.
4. Apply supplemental nutrients as needed to maintain the desired species composition and stand density of herbaceous vegetation.

5. Maintain or restore the treatment strip as necessary by periodically grading when deposition jeopardizes its function, and then reestablishing to herbaceous vegetation.
6. Routinely de-thatch and/or aerate treatment strips used for treating runoff from livestock holding areas in order to promote infiltration.
7. Conduct maintenance activities only when the treatment strip is dry and moisture content in the surface soil layer will not allow compaction.
8. Prevent grazing in treatment strips.

### **SUPPORTING DATA AND DOCUMENTATION**

The following is a list of the minimum data and documentation to be recorded in the case file:

1. Extent of planting in acres, field number where the practice located, and the location of the practice marked on the conservation plan map.
2. Assistance notes.

#### **Field Data and Survey Notes.**

The following is a list of the minimum data needed:

1. Plan view sketch.
2. Slope of the treatment strip.
3. Cross-section (minimum of one per reach not to exceed 300 feet).
4. Lengths of treatment strip.
5. Profile and cross-section of outflow conveyance and, special precautions if needed.

#### **Design Data**

Record on appropriate engineering paper. For guidance on the preparation of engineering plans see Chapter 5 of the Engineering Field Handbook

- Part 650. The following is a list of the minimum required design data:

1. Locate the practice on the farm plan map in the case file.
2. Determine soil type and any special restrictions.
3. Determine peak runoff from the contributing drainage area for the required design storm in accordance with Chapter 2 of the Engineering Field Handbook - Part 650 or by other approved method.
4. Design the treatment strip to meet the criteria of this practice standard.
5. Show job class on the plan.
6. Plan view sketch, profile of the treatment strip to be shown on plans.
7. Quantities estimate.
8. Details of outflow conveyance or other structural components needed.
9. Planting plan. This must meet the criteria, specifications and documentation requirements of the conservation standard for Critical Area Planting (Code 342). Show on the plans.
10. Written Operation and Maintenance Plan.

#### **Specifications**

Specifications will include:

1. Length, width, and slope of the treatment strips to accomplish the planned purpose (length refers to flow length down the slope of the treatment strip).
2. Herbaceous species and seed selection, and seeding rates to accomplish the planned purpose.
3. Planting dates, care, and handling of the seed to ensure that planted material have an acceptable rate of survival.

4. Statement that only viable, certified weed free, high quality, and regionally adapted seed will be used.
5. Site preparation sufficient to establish and grow selected species.

**Construction Check Data/As-Built Plans**

Record on survey notepaper, NRCS-ENG-28, or other appropriate engineering paper. Survey data will be plotted in red. The following is a list of minimum data needed for As-built documentation:

1. Documentation of site visits on CPA-6. The documentation shall include the date, who performed the inspection, specifics as to what was inspected, all alternatives discussed, and decisions made and by whom.
2. Check notes recorded during or after completion of construction showing grade and cross section of the constructed treatment strip and outflow conveyance including length, width, and depth.
3. Calculate acreage.
4. Statement on seeding and fencing.
5. Final quantities and documentation for quantity changes. Materials certifications as appropriate.
6. Sign and date check-notes and plans by someone with appropriate approval authority. Include statement that practice meets or exceeds plans and NRCS practice standards.